Banksia DC Ceiling Fan with Remote



Installation Guide

In the box

1 x DC motor with ceiling canopy and mounting bracket · 3 x ABS blades · downrod (12.5 cm or 20 cm on the 106, 132 and 152 cm sizes) · 1 x receiver · 1 x remote control · fixings

You will need

Drill, screwdrivers, stepladder and a helper. A ceiling joist or rated fan bracket to fix to. No light kit: this model has no integrated light. In Australia, fan blades must be at least 2.1 m above the floor.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- A fan must be fixed to a ceiling joist or a rated fan bracket, never to plasterboard alone.
- Follow the detailed manufacturer instructions in the box for torque and balancing.

Step by step

1. **Fix the bracket**
   Screw the mounting bracket securely into a ceiling joist or a rated fan bracket, with the supply cable coming through the centre.
2. **Fit the downrod and hang the motor**
   Feed the motor wires through the downrod (where supplied) and fix it to the motor as shown in the manufacturer instructions, then hang the motor on the bracket.
3. **Connect the wiring**
   With the power OFF, connect the receiver to the supply: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted. Connect the receiver to the motor, fit it inside the canopy and secure the canopy.
4. **Fit the blades**
   Fix the three blades to the motor with the screws supplied, tightening each one firmly and evenly.
5. **Pair the remote**
   Pair the remote with the receiver as described in the manufacturer instructions.
6. **Test**
   Restore the power at the switchboard and run the fan through its speeds with the remote.

Care and cleaning

Switch the fan off and wait for the blades to stop. Wipe the blades and motor with a soft, dry or slightly damp cloth. Do not bend the blades; check the screws are tight once a year.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.