Alba Alabaster Wall Light

Installation Guide



In the box

1 x Alba wall light (1, 2 or 3 alabaster blocks on black metal brackets, integrated warm white LED) · mounting plate · wall plugs and screws.

You will need

Drill, screwdriver, spirit level, pencil and wire strippers. No globe to buy: the LED is built in.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Natural alabaster: every block has its own veining, tone and small marks. These are part of the stone, not defects.
- The stone is heavy and can chip: fix the plate into solid wall or use anchors rated for the weight, and handle each block with care.
- Indoor use. In a bathroom, only outside the wet zones: ask your electrician.
- Hardwired fitting: must be installed by a licensed electrician.

Step by step

1. **Turn off the power**
   Switch off the circuit at the switchboard and check the wall point is dead.
2. **Fix the mounting plate**
   Hold the plate against the wall, level it and mark the holes. Drill, fit the plugs and screw the plate on firmly.
3. **Connect the wiring**
   Active to L, Neutral to N and Earth to the earth terminal. Check every connection is tight and insulated.
4. **Mount the light**
   Fit the frame onto the plate and secure it, then seat each alabaster block on its bracket. Tighten gently: never force a screw against stone.
5. **Test**
   Restore the power and switch on. The integrated LED gives a warm white glow through the stone.

Care and cleaning

Switch off and let it cool. Dust the stone with a soft dry cloth. Alabaster is soft and porous: never use water, acidic, abrasive or bathroom cleaners on it.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.