Chinook LED Ceiling Fan with Remote

Installation Guide



In the box

1 x fan motor with LED light and diffuser · 3 x blades · canopy and mounting bracket · remote control · fixing hardware

You will need

Drill, screwdrivers, spanner, stepladder and a helper. No globe needed: the 30 W LED light is built in. A wall switch is not included.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- A fan must be fixed to a ceiling joist or a rated fan bracket, never to plasterboard alone.
- Follow the detailed manufacturer instructions in the box for torque and balancing.

Step by step

1. **Fix the bracket**
   Fix the mounting bracket securely into a ceiling joist or a rated fan bracket, using fixings suited to the fan's weight.
2. **Hang the motor**
   Assemble the canopy and any downrod supplied as shown in the manufacturer instructions, then lift the motor onto the bracket and seat it securely.
3. **Connect the wiring**
   With the power OFF, connect the fan to the supply: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted. Tuck the wires in and secure the canopy.
4. **Fit the blades**
   Attach the three blades to the motor with the screws supplied and tighten each one firmly and evenly.
5. **Fit the diffuser and pair the remote**
   Fit the acrylic diffuser over the LED light. Pair the remote as described in the manufacturer instructions, then check the speeds, light colours, reverse and timer.
6. **Test**
   Restore the power at the switchboard and switch on the light.

Care and cleaning

Switch the fan off and wait until it stops completely. Wipe the blades, motor and diffuser with a soft, dry or slightly damp cloth. Never bend the blades or use solvents.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.