# Eden Travertine & Wood Pendant Light

Installation Guide



### In the box

1 x travertine shade with lampholder · 1 x ceiling canopy with mounting bracket · adjustable cable · screws and wall plugs

### You will need

Drill, screwdriver, pencil and stepladder. One globe, sold separately: ES (E27) for the Cylinder, G9 (max. 60 W) for the Dome (warm white LED, 2700 to 3000K, recommended). Hang about 75 cm above a table (70 to 80 cm over an island).

### Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Natural travertine is fragile: unpack and handle the shade with care.
- Dimming needs a dimmable globe and a compatible wall dimmer.

## Step by step

1. **Fix the mounting bracket**
   Separate the canopy from its bracket. Mark the holes and fix the bracket firmly to the ceiling, into a joist or with suitable plasterboard anchors.
2. **Set the drop**
   Adjust the cable at the canopy: Cylinder up to 180 cm, Dome 200 cm. Your electrician can trim any extra.
3. **Connect the wiring**
   With the power OFF, connect the cable to the supply: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted.
4. **Fit the canopy**
   Push the canopy up over the bracket, tuck the wires neatly inside and tighten the screws until it sits flush with the ceiling.
5. **Fit the globe**
   Cylinder: screw in an ES (E27) globe. Dome: push in a G9 globe. Fit it gently, without force.
6. **Test**
   Restore the power at the switchboard and switch on the light.

### Care and cleaning

Turn the light off and let it cool. Dust with a soft, dry cloth. No water, solvents or abrasives on the stone.

### Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.