Esme Wood & Alabaster-Look Ceiling Light

Installation Guide



In the box

1 x Esme ceiling light (wood disc, beaded wood stem, brass-finish canopy, alabaster-look glass diffuser, Ø34 x 22 cm) with integrated LED · mounting bracket · wall plugs and screws.

You will need

Drill, screwdriver, spirit level, pencil, wire strippers and a stable ladder.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Integrated LED, 18 W, 3 light colours: no globe to buy or change.
- Fix the bracket into a ceiling joist or use anchors rated for the weight.
- Indoor use only.
- Hardwired fitting: must be installed by a licensed electrician.

Step by step

1. **Turn off the power**
   Switch off the circuit at the switchboard and check the ceiling point is dead.
2. **Fix the mounting bracket**
   Hold the bracket against the ceiling, mark the holes, drill, fit the plugs and screw the bracket on firmly.
3. **Connect the wiring**
   Active to L, Neutral to N and Earth to the earth terminal. Check every connection is tight and insulated.
4. **Fit the canopy**
   Lift the light into place and secure the brass-finish canopy to the bracket.
5. **Fit the diffuser**
   Attach the alabaster-look glass diffuser under the wood disc and secure it gently.
6. **Test**
   Restore the power and switch on.

Care and cleaning

Switch off and let it cool. Dust the wood and glass with a soft dry cloth. Avoid water, solvents and abrasive cleaners on the wood.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.