Flora Scalloped Fabric Pendant Light

Installation Guide



In the box

1 x 45 cm scalloped fabric shade with lampholder · 1 x ceiling canopy with mounting bracket · adjustable suspension cable (150 cm) · fixing hardware

You will need

Drill, screwdriver, pencil and stepladder. One ES (E27) globe, sold separately (warm white LED, 2700 to 3000K, recommended). Hang the shade about 75 cm above a table or bench (70 to 80 cm over an island).

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Fabric shade: use an LED globe only and keep it from touching the fabric.

Step by step

1. **Fix the mounting bracket**
   Separate the canopy from its bracket and screw the bracket to the ceiling, into a joist or with suitable plasterboard anchors.
2. **Set the drop**
   Adjust the suspension cable (150 cm) to the drop you want and lock it. Your electrician can trim any extra cable.
3. **Connect the wiring**
   With the power OFF, connect the pendant cable to the supply wires: Active to L, Neutral to N, and Earth if fitted.
4. **Fit the canopy**
   Tuck the wires in, push the canopy over the bracket and tighten the side screws until it sits flush.
5. **Fix the shade**
   Fit the shade onto the lampholder fitting and tighten its side screws evenly by hand.
6. **Fit the globe**
   Screw an ES (E27) LED globe into the lampholder, gently and without force.
7. **Test**
   Restore the power, switch on, and ease the scalloped panels into shape if needed.

Care and cleaning

Turn the light off and let it cool. Dust the fabric with a soft brush or a lint roller. Do not wet or wash the shade.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.