Hazel Nordic White & Wood Pendant Light

Installation Guide

In the box

1 x white metal shade (Ø 30 cm) with wood-look top and lampholder · 100 cm adjustable cable · ceiling canopy (Ø 10 cm) with mounting bracket · fixing hardware

You will need

Drill, screwdriver, wire cutters, pencil and stepladder. One ES (E27) globe, sold separately (warm white LED, 2700 to 3000K, recommended).

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Fix the bracket to a ceiling joist or solid support, not to plasterboard alone.
- Decide the hanging height before installation; the electrician can shorten the cable.

Step by step

1. **Power off**
   Switch off the circuit at the switchboard before starting.
2. **Fix the bracket**
   Separate the canopy from its bracket. Mark the holes and screw the bracket firmly into a ceiling joist or a solid support.
3. **Set the drop**
   Adjust the cable to the height you want and cut any excess, leaving enough length to connect.
4. **Connect the wiring**
   Connect the light to the supply: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted.
5. **Fit the canopy**
   Tuck the wires neatly inside, then fit the canopy over the bracket and secure it flush with the ceiling.
6. **Fit the globe and test**
   Screw an ES (E27) globe into the lampholder inside the shade, then restore the power and switch on.

Care and cleaning

Switch off and let the globe cool first. Wipe the shade with a soft, dry or slightly damp cloth and avoid abrasive cleaners.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.