Kai Low-Profile DC Ceiling Fan with LED Light

Installation Guide

In the box

1 x low-profile ceiling fan with LED light · 3 x blades · remote control with batteries · installation accessories · instruction manual

You will need

Drill, screwdrivers, spanner, stepladder and a helper. No globe needed: the dimmable LED light is built in. Check the clearance around the 132 cm blade span before choosing the position.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- A fan must be fixed to a ceiling joist or a rated fan bracket, never to plasterboard alone.
- Follow the detailed manufacturer instructions in the box for torque and balancing.

Step by step

1. **Fix the bracket**
   Fix the mounting bracket securely into a ceiling joist or a rated fan bracket, using fixings suited to the fan's weight.
2. **Hang the fan**
   Kai is low-profile and mounts close to the ceiling with no downrod. Lift the fan onto the bracket and seat it as the manual shows.
3. **Connect the wiring**
   With the power OFF, connect the fan to the supply: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted. Tuck the wires in and secure the canopy.
4. **Fit the blades**
   Attach the three blades with the screws supplied and tighten each one firmly and evenly.
5. **Pair the remote**
   Fit the batteries and pair the remote (and the app, if you use it) as described in the manual. Check the 6 speeds, reverse, light colour and dimming.
6. **Test**
   Restore the power at the switchboard and switch on the light.

Care and cleaning

Switch the fan off and wait until it stops completely. Wipe the blades, housing and light with a soft, dry or slightly damp cloth. Never bend the blades or use solvents.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.