Kumo Three-Tier Rice Paper Lantern Lamp

Installation Guide

In the box

1 x three-tier paper shade on a fine wire frame · slender metal legs · ES (E27) lampholder with 150 cm plug-in cord

You will need

No tools usually needed. One ES (E27) globe, sold separately (warm white LED, 2700 to 3000K, recommended). A flat, stable surface near a power point.

Important safety information

- Indoor use only. Keep the lamp dry and away from water, heaters and open flames.
- Use a power point in good condition, and unplug the lamp before cleaning or moving it, or changing the globe.
- Plug-in lamp: no electrician needed.
- Paper shade: use a cool-running LED globe and keep the lamp away from water, heaters and open flames.

Step by step

1. **Unpack**
   Unpack carefully and gently open out the paper shade. Avoid pressing on the paper.
2. **Assemble**
   Fit the legs and the light fitting to the frame as shown in the box instructions.
3. **Fit the globe**
   Screw an ES (E27) LED globe into the lampholder, gently and without force.
4. **Position the lamp**
   Place the lamp on a stable, flat surface, with the cable clear of walkways.
5. **Plug in and switch on**
   Plug into a power point and switch on.

Care and cleaning

Switch off, unplug and let the lamp cool. Dust the paper shade gently with a soft, dry brush. Never use water on the paper.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.