Margot Art Deco Glass Flush Ceiling Light

Installation Guide



In the box

1 x ribbed opal glass shade · 1 x round base with integrated LED and central threaded rod · chrome cap and finial · screws and wall plugs · terminal block

You will need

Drill, screwdriver, pencil and stepladder. No globe needed: the 3000K warm white LED is built in.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Indoor use in dry areas only (IP20); not for bathrooms.
- Works with a standard on/off wall switch.

Step by step

1. **Connect the wiring**
   With the power OFF, connect the supply to the terminal block on the base: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted.
2. **Fix the base to the ceiling**
   Hold the base flat against the ceiling, mark the holes, then screw it on directly, into a joist or with suitable plasterboard anchors. Keep the wires tucked inside.
3. **Fit the glass shade**
   Lift the shade over the threaded rod in the centre of the base, add the chrome cap and screw the finial on by hand until the shade is held firmly. Do not overtighten.
4. **Test**
   Restore the power at the switchboard and switch on the light.

Care and cleaning

Turn the light off and let it cool. Wipe the glass with a soft, dry or slightly damp cloth and polish the chrome with a dry cloth. Avoid abrasive cleaners.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.