Mesa Square Travertine & Walnut Wall Light

Installation Guide



In the box

1 x travertine light body on a walnut wall plate, with warm white LED · mounting bracket and fixings

You will need

Drill, screwdriver, pencil and spirit level. No globe needed: the warm white LED is included. Suggested height: centre about 120 to 140 cm from the floor beside a bed, 150 to 170 cm in a living room or hallway.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Indoor use in dry areas only.
- Natural travertine: each piece varies. Handle the stone with care.

Step by step

1. **Remove the bracket**
   Separate the wall plate from its mounting bracket. Keep the screws.
2. **Fix the bracket to the wall**
   Hold the bracket in place, check it is level and mark the holes. Drill, insert the wall plugs and screw the bracket firmly to the wall, with the supply cable coming through the centre.
3. **Connect the wiring**
   With the power OFF, connect the light to the supply: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted. Tuck the wires neatly behind the backplate.
4. **Fit the light**
   Place the wall plate over the bracket and secure it with the screws provided, checking the light sits straight.
5. **Test**
   Restore the power at the switchboard and switch on the light.

Care and cleaning

Turn the light off and let it cool. Dust the stone and walnut with a soft, dry cloth. Do not use water, solvents or abrasive cleaners on the stone.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.