
Mochi Silk-Look Pebble Ceiling Light

Installation & care guide · Aussie Lights



Ø 50 cm x 18 cm high, flush ceiling mount. Iron frame with a handmade silk-look fabric shade. Integrated 38 W LED (included), 3 light colours: warm, neutral and cool white. Suits rooms of about 10-15 m².

Before you start

- This is a hardwired ceiling light. In Australia it must be installed by a licensed electrician.
- Turn off the power at the switchboard before installation, cleaning or maintenance.
- Indoor use, in dry areas.
- The shade is handmade fabric: unpack it on a clean, soft surface and avoid pressing or crushing the folds.

In the box

- Silk-look fabric shade on its iron frame, with integrated LED
- Ceiling mounting plate, screws and wall plugs

Installation steps

1. Check that nothing is missing or damaged before the electrician arrives.
2. Your electrician fixes the mounting plate to the ceiling over the electrical point.
3. Your electrician connects the light to the mains wiring (active, neutral and earth).
4. Attach the light to the mounting plate and check it sits flat against the ceiling.
5. Restore power and test the light.

Changing the light colour

Use your normal wall switch. Turn the light off, then on again within a couple of seconds to move to the next colour: warm white, neutral white, then cool white.

Care

- Switch off and let the light cool, then dust gently with a soft dry brush or a hair dryer on the cool setting.
- Do not use water, solvents or cleaning products on the fabric.
- Contact us if you have any issue with the light.

Need help? Contact Aussie Lights through the contact page on aussielights.com.