Nara Travertine & Walnut Flush Mount Ceiling Light



Installation Guide

In the box

1 x travertine light body with walnut-tone ceiling base and integrated LED · mounting bracket · fixing hardware

You will need

Drill, screwdriver, pencil and stepladder. No globe needed: the warm white LED is built in.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Natural travertine is fragile and varies from piece to piece: handle the light with care.

Step by step

1. **Remove the bracket**
   Separate the mounting bracket from the ceiling base. Keep the screws.
2. **Fix the bracket**
   Hold the bracket against the ceiling, mark the holes and fix it firmly into a joist or with suitable plasterboard anchors, with the supply cable coming through the centre.
3. **Connect the wiring**
   With the power OFF, connect the light to the supply: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted.
4. **Fit the light**
   Tuck the wires neatly into the base, then fit the light onto the bracket and secure it so the base sits flush with the ceiling.
5. **Test**
   Restore the power at the switchboard and switch on the light.

Care and cleaning

Turn the light off and let it cool. Dust the stone and wood with a soft, dry cloth. Do not use water, chemical solvents or abrasive cleaners on the stone.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.