Ondine Wave LED Linear Pendant Light

Installation Guide



In the box

1 x wave LED pendant · ceiling canopy with mounting bracket · adjustable suspension · remote control (remote version only) · fixings

You will need

Drill, screwdriver, pencil and stepladder. A helper to hold the light. No globe needed: the LED is built in. Hang it about 75 cm above a table (70 to 80 cm over an island).

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Longer lengths need two people to lift and level the light.
- Remote version: pair and use the remote as shown in the box instructions.

Step by step

1. **Fix the mounting bracket**
   Separate the canopy from its bracket. Mark the holes and fix the bracket firmly to the ceiling, into a joist or with suitable plasterboard anchors.
2. **Set the drop**
   Adjust the suspension at the canopy to the drop you want (up to 200 cm) and lock it in place. Your electrician can trim any extra cable.
3. **Connect the wiring**
   With the power OFF, connect the cord to the supply: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted.
4. **Fit the canopy**
   Push the canopy up over the bracket, tuck the wires neatly inside and secure it until it sits flush with the ceiling.
5. **Level the light**
   Check the light hangs level along its length and fine-tune the suspension if needed.
6. **Test**
   Restore the power at the switchboard and switch on the light.

Care and cleaning

Turn the light off and let it cool. Wipe the bar and LED tube with a soft, dry cloth. Do not use water, solvents or abrasive cleaners.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.