Perla Travertine Wall Light

Installation Guide



In the box

1 x travertine backplate · 1, 2 or 3 opal glass globes · warm white LED · mounting bracket, screws and wall plugs

You will need

Drill, screwdriver, pencil and spirit level. Suggested height: centre about 150 to 170 cm from the floor, or level with the middle of a mirror.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Indoor, dry areas only. Must be installed by a licensed electrician.
- Stone and glass are fragile: unpack on a soft surface.

Step by step

1. **Unpack with care**
   Lay the parts on a soft blanket and check nothing is missing.
2. **Mark and drill**
   Hold the bracket against the wall, check it is straight with a spirit level and mark the holes. Check for hidden pipes or cables, then drill.
3. **Fix the bracket**
   Push in the wall plugs and screw the bracket firmly to the wall, with the supply cable coming through the centre.
4. **Connect the wiring**
   With the power OFF, connect Active to L, Neutral to N and Earth to the earth terminal. Tuck the wires neatly behind the backplate.
5. **Mount the backplate**
   Fit the travertine backplate onto the bracket, check it is level and tighten the fixing screws.
6. **Fit the globes**
   Check the LED light source is in place, then fit each opal glass globe gently. Do not overtighten.
7. **Test**
   Restore the power at the switchboard and switch on the light.

Care and cleaning

Switch off and let it cool. Dust the stone with a soft dry cloth; avoid water, chemicals and acidic cleaners.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.