Posy Woven Fibre Flower Pendant Light

Installation Guide



In the box

1 x woven fibre flower shade on black metal frame with lampholder · 1 x ceiling canopy with mounting bracket · 120 cm adjustable cable · fixings

You will need

Drill, screwdriver, pencil and stepladder. One ES (E27) globe, max. 40 W (warm white LED, 2700 to 3000K, recommended).

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- The shade is natural woven fibre: keep the globe at 40 W or less and use an LED globe so the shade stays cool.

Step by step

1. **Fix the mounting bracket**
   Undo the side screws to separate the canopy from its plate. Mark and drill the holes, insert the wall plugs and screw the plate firmly to the ceiling.
2. **Set the drop**
   Adjust the cable at the canopy to the drop you want (up to 120 cm) and lock it in place. Your electrician can trim any extra cable.
3. **Connect the wiring**
   With the power OFF, connect the cord to the supply with the connectors supplied: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted.
4. **Fit the canopy**
   Tuck the wires inside, push the canopy up over the plate and refit the side screws until it sits flush with the ceiling.
5. **Check the petals**
   Make sure each petal sits evenly on the frame. Do not bend the metal edging sharply.
6. **Fit the globe and test**
   Screw an ES (E27) LED globe, max. 40 W, into the lampholder. Restore the power at the switchboard and switch on the light.

Care and cleaning

Turn the light off and let it cool. Dust with a soft dry brush or a vacuum on low with a brush head. Keep away from moisture.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.