Quill Recessed Bedside Reading Wall Light

Installation Guide



In the box

Recessed wall light with swivel head, push button and integrated LED (two lights for the Pair) · mounting box · terminal block · screws

You will need

Pencil, spirit level, plasterboard saw, screwdriver. No globe needed: the LED is built in. Suggested height: centre about 120 to 150 cm from the floor beside a bed, within reach from the pillow.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Recessed fitting: needs a wall cavity at least 4.6 cm deep (plasterboard or a timber headboard panel). Best planned during a renovation.
- Indoor dry areas only (IP20): not for bathrooms.

Step by step

1. **Mark and cut the opening**
   Mark a level 16 x 4.5 cm opening, check for studs, pipes and cables, cut it and bring the supply cable through.
2. **Fit the mounting box**
   If the wall needs it, screw the mounting box into the opening with the two screws supplied.
3. **Connect the wiring**
   With the power OFF, use the terminal block: Active to L, Neutral to N, Earth to the earth terminal if fitted.
4. **Fix the light**
   Push the light into the opening and screw the face plate through its top and bottom holes until flush.
5. **Test**
   Restore the power, switch on and check the head swivels freely and folds flat.

Care and cleaning

Turn the light off. Wipe the plate and head with a soft, dry cloth. Do not use water, solvents or abrasive cleaners.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.