Rhea Travertine Wall Light

Installation & care guide · Aussie Lights



Size: 19 cm wide x 16 cm high. Fitting: 2 x G9 globes (sold separately).

Before you start

- This is a hardwired wall light. In Australia it must be installed by a licensed electrician.
- Turn off the power at the switchboard before installation, cleaning or maintenance.
- Indoor use. In a bathroom, install it outside the wet zones (away from showers and baths), for example above a vanity mirror.
- The body is natural travertine: unpack it on a soft surface and handle with care. Every stone has its own pores and tone.

In the box

- Curled travertine wall light with walnut wood wall plate
- Mounting plate and screws

Installation steps

1. Check that nothing is missing or damaged before the electrician arrives.
2. Your electrician fixes the mounting plate to the wall over the electrical point, level and centred (for example above a mirror, a bedside table or a piece of art).
3. Your electrician connects the light to the mains wiring (active, neutral and earth).
4. Fit the light onto the mounting plate and tighten the screws. Check it sits level.
5. Fit two G9 LED globes (warm white 2700-3000K suggested) behind the curled stone, then restore power and test.

Care

- Switch off and let the light cool, then dust with a soft dry cloth.
- Do not use water, solvents or abrasive cleaners on the stone or wood.
- Contact us if you have any issue with the light.

Need help? Contact Aussie Lights through the contact page on aussielights.com.