# Sasso Travertine Spotlight Ceiling Light

Installation Guide



### In the box

1 x Ø 30 cm wood ceiling base with 3 adjustable travertine spotlights and LED light sources · mounting bracket · screws and wall plugs

### You will need

Drill, screwdriver, pencil and stepladder. LED light sources are included: no globe to buy.

### Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- Hardwired: installation must be carried out by a licensed electrician.
- Natural travertine is fragile and varies from piece to piece: handle the spots with care.

## Step by step

1. **Unpack with care**
   Lay the base and the stone spots on a soft blanket and check that all parts are present.
2. **Fix the bracket**
   Hold the bracket against the ceiling, mark the holes and fix it firmly into a joist or with suitable anchors, with the supply cable through the centre.
3. **Connect the wiring**
   With the power OFF, connect Active to L, Neutral to N and Earth to the earth terminal.
4. **Mount the base**
   Tuck the wires into the base, fit it onto the bracket and tighten the screws so it sits flush with the ceiling.
5. **Aim the spots**
   Gently tilt and turn each travertine spot to point the light where you need it.
6. **Test**
   Restore the power at the switchboard and switch on the light.

### Care and cleaning

Turn the light off and let it cool. Dust the stone and wood with a soft, dry cloth. Avoid water, chemicals and acidic cleaners on the travertine.

### Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.