Sloane Fluted Outdoor LED Wall Light

Installation Guide

In the box

1 x Sloane wall light (60, 75, 100 or 120 cm) with integrated LED in warm white or cool white · wall bracket · wall plugs and screws

You will need

Drill, screwdriver, spirit level, pencil and wire strippers. A second person helps for the 100 and 120 cm sizes. Weatherproof connector and exterior-grade sealant for the cable entry.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- IP65 rated by the maker for exterior walls. Seal the cable entry so water cannot run into the wall box.
- Every size is 16 cm wide and sits 12 cm out from the wall. Mount it upright, on a flat, solid wall.
- The LED is built in and is not replaceable. The light colour (warm white or cool white) is the one you ordered.
- Hardwired fitting: must be installed by a licensed electrician.

Step by step

1. **Turn off the power**
   Switch off the circuit at the switchboard and check the wall point is dead before you start.
2. **Mark and fix the bracket**
   Hold the bracket against the wall, check it is plumb with a spirit level and mark the holes. Drill, fit the wall plugs and screw the bracket on firmly.
3. **Connect the wiring**
   Active to L, Neutral to N and Earth to the earth terminal. Use a weatherproof connector and check every connection is tight and insulated.
4. **Seal the cable entry**
   Seal around the cable where it leaves the wall with exterior-grade sealant so no water can track behind the light.
5. **Mount the light**
   Fit the light onto the bracket, tighten the fixing screws and check it sits flush against the wall.
6. **Test**
   Restore the power and switch on. Peel off any protective film from the diffuser.

Care and cleaning

Switch off before cleaning. Wipe the frame and the fluted diffuser with a soft damp cloth and mild soapy water, then dry. Never use a pressure washer, solvents or abrasive cleaners.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.