Talo Travertine & Wood Wall Light

Installation Guide



In the box

1 x wooden base with 2 or 3 travertine shades and integrated LED · 1 x mounting plate with two threaded studs · 2 x hand nuts · terminal block · screws and wall plugs

You will need

Drill, screwdriver, pencil and spirit level. No globe needed: the 3000K LED is built in. Suggested height: just above a mirror, or about 150 to 170 cm from the floor in a living room or hallway.

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- In bathrooms, install away from direct water spray, never inside the shower.
- Works with a standard on/off wall switch.

Step by step

1. **Fix the mounting plate**
   Check for hidden pipes or cables, mark the holes level, drill, and screw the mounting plate firmly to the wall, with the supply cable beside it.
2. **Connect the wiring**
   With the power OFF, connect the supply to the light through the terminal block: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted.
3. **Fit the light**
   Tuck the wires into the wall, slide the base over the two studs on the plate and tighten the two hand nuts by hand until it sits firmly against the wall.
4. **Angle the shades**
   Gently rotate each shade to aim the light onto the mirror or across the wall.
5. **Test**
   Restore the power at the switchboard and switch on the light.

Care and cleaning

Turn the light off and let it cool. Dust the stone and wood with a soft, dry cloth. Do not use water, chemical solvents or abrasive cleaners on the stone.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.