Vika Nordic Slim Pendant Light

Installation Guide



In the box

Single: 1 x pendant (metal shade, timber neck) with 100 cm cable, ceiling canopy and fixings. 3-light set: 3 x pendants on a Ø 30 cm round ceiling plate, with fixings.

You will need

Drill, screwdriver, pencil and stepladder. One globe per pendant to suit the lampholder (see the product page), sold separately; warm white LED, 2700 to 3000K, recommended. Hang the shade about 75 cm above a table or bench (70 to 80 cm over an island).

Important safety information

- This light must be installed by a licensed electrician, in line with AS/NZS 3000 (Wiring Rules) and local regulations.
- Turn the power off at the switchboard before installing, cleaning or servicing the light.
- Use screws and wall plugs suited to your wall (plasterboard, timber or masonry).
- 3-light set: stagger the three drops for a relaxed cluster.
- Use LED globes and do not exceed the maximum wattage shown on the lampholder.

Step by step

1. **Fix the mounting bracket**
   Separate the canopy or round plate from its bracket. Mark the holes and fix the bracket firmly to the ceiling, into a joist or with suitable plasterboard anchors.
2. **Set the drop**
   Adjust each cable at the canopy or plate to the drop you want and lock it in place. Your electrician can trim any extra cable.
3. **Connect the wiring**
   With the power OFF, connect the pendant cable(s) to the supply: Active to L, Neutral to N, and Earth to the earth terminal if one is fitted.
4. **Fit the canopy or plate**
   Push the canopy or plate up over the bracket, tuck the wires neatly inside and secure it flush with the ceiling.
5. **Fit the globes**
   Fit a globe into each lampholder, gently and without force.
6. **Test**
   Restore the power at the switchboard and switch on the light.

Care and cleaning

Turn the light off and let it cool. Wipe the metal shade and timber neck with a soft, dry cloth. Do not use water, solvents or abrasive cleaners.

Need help?

Email hello@aussielights.com with your order number and a photo. Your light is covered by our 2-year warranty and 30-day returns.